

Quick Start Guide

See owner's manual for complete instructions and important safety information before using this product.



POWER GRILL 360 PLUS™

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Check all packaging material thoroughly for accessories. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).

AIR FRYING

Step 1

Insert the Air Fryer Drip Tray below the bottom heating elements (at the very bottom of the appliance).



Step 2

Place food on the Crisper Tray and slide the Tray into shelf on the inside of the appliance.

NOTE: The Wire Rack or Baking Pan also slide into the shelves (only two accessories will fit in the shelves at once).



Step 3

Use the Control Knob to select the Air Fry cooking preset.



Step 4

Press the Control Knob to begin the cooking process.

NOTE: You can press the Control Knob to pause any cooking cycle.



Step 5

When the cooking cycle is complete, use oven mitts or potholders to remove the Crisper Tray by sliding it out of the appliance.



Quick Start Guide

See owner's manual for complete instructions and important safety information before using this product.



POWER GRILL 360 PLUS™

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Check all packaging material thoroughly for accessories. Wash with warm, soapy water before first use (only select accessories are dishwasher safe).

GRILLING

Step 1

Assemble the appliance and ensure that the Grill Plate and Grill Drip Tray are in place (see owner's manual for detailed instructions).



Step 2

Use the Control Knob to select the Grill cooking preset. Allow the appliance to preheat.

NOTE: The Wire Rack or Baking Pan also slide into the shelves (only two accessories will fit in the shelves at once).



Step 3

When the appliance has preheated, place food on the grilltop and cover with the Glass Lid.



Step 4

Press the Control Knob to begin the cooking process. Flip your food halfway through the cooking process and replace the Glass Lid to finish cooking.

NOTE: You can press the Control Knob to pause any cooking cycle.



Step 5

When the cooking cycle is complete, use tongs or a spatula to remove the food.

